



**NOTES:**

- minimum flashing height to be 8" above membrane surface
- adhere thermoplastic membrane to substrate using manufacturer supplied bonding adhesive
- wipe all membrane surfaces with acetone prior to heat-welding ply/membrane surfaces